Floor & Rudder Pedal Clamps See Drwg # J2-L 41

Rear Floor (E2-606) 1/4" 3 Ply White Pine

6 5/8"

24 3/4"

Torque Tube Pulley Cover Placed Here See Drwg # J2-A61.

12"

24 1/8"

3 1/2"

1"

1"

1"

2 1/2"

Front Floor (E2-605) 1/4" 3 Ply White Pine

19 3/4"

5 Bulkheads Spaced Length of Seat 25

1/4"

Aileron Pulley Cover Placed here See Drwg No J2-A60

Rudder Pedal Hec. Wells (Alternate) See Drwg # J2-65

3 1/2"

Ⓒ

Ⓑ

E2-642

E2-644

Front Seat Back

See Detail "A"

5 3/4"

2 1/4"

2 1/4"

2-10-32 Bolts

1 1/2"

5 3/4"

Ⓐ

1/4 Dia. Hole

5"

7 1/2"

2"

1 1/4"

3/16"

5/16"

5/16"

1 7/16"

3 7/16"

1 23/32"

7/16 Drill 2 HOLES

Ⓐ

2 Holes - 5/8" Drill

DETAIL "A" SEAT BULKHEAD CABLE GUIDE (J2-836)

1 Req'd Scale-Full Size

Mail-Fibre (Bonetford)

Note: For all other dimensions not given see drwg # E2-L 60

ELIGIBLE FOR USE ON ALL E2, F2, H2 & J2 MODELS

JUL 5 1961

Scale: 3"=1 Ft.

TAYLOR AIRCRAFT COMPANY

LAYOUT OF SEATS & FLOOR (ALTERNATE)

LET.	REVISION	DATE	SR.	DRAWN	CHECKED	APPROVED
D	Part Nos Added	5-12-37				
C	WAS 3/4	E.J.B. 12-7-36				
B	WAS 2"	E.J.B. 6-2-36		E.J.B.	D.E.L.	
A	[illegible]	E.J.B. 4-15-36		7-23-36	5-27-37	

J2-A62